


MC888S Manual Software Upgrade Guidance

1. Connect to MC888S through WiFi using Phone or Laptop.
2. Open Web browser and key in "192.168.0.1".


(1) Laptop view:



(2) Phone view can change to Laptop view by clicking PC as show below.




3. Key in password "admin" and Login.




4. Go to [Advanced Settings](#) at the bottom of page.





6. Follow the instruction and click **Update**.

7. The device will download the software and click “OK” once it is finished downloading. The device will restart to finish the update. The overall update process will take about 15min. **Please wait patiently and do not turn off the power.**



8.The device will download the software and click “OK” once it.
Latest version after successful update will be “CR_UMMYMC888SV1.0.0B09”

